

## YAMAHA DTX900 QUICK START – VOICE SELECT


### PLAY the DRUM KIT:

Press the **[DRUM KIT]** mode button, then press **[F1] [PLAY]** to access the main kit play mode. Use the jog-dial or the INC/DEC buttons to select a drum kit in the PRESET Bank 01-50.

### Change the drum VOICE SET:

A VoiceSet assigns *multiple sounds* to all sources of a multi-zone INPUT in one step.

1. While in DRUM KIT mode, press **[F2] VOICE** to access voice functions. Note the screen now includes several icons above the SF or “sub-function” keys. Press **[SF1]** to access voice **SELECT**.
2. Strike any zone of a trigger to select that trigger INPUT<sup>①</sup> for editing. Use the cursor to highlight the Voice Set number<sup>③</sup>. Rotate the jog-dial or press the INC/DEC buttons to select a new Voice Set. If desired, you can change the category of Voice Set<sup>②</sup> to the left of the voice set number.




NOTE: The icons above the [SF1-SF4] keys are square, indicating a new page of the DTX9000. The “Source” and “key” icons have round edges, indicating a button or switch.

### Change the drum VOICE:

A *single* drum Voice can be assigned to any SOURCE from a multi-zone pad/trigger.

3. From Drum Kit **[F2] VOICE**→ **[SF1] SELECT** page press the **[SF5] SOURCE**<sup>④</sup> button<sup>1</sup>. Strike a trigger zone or kick the pedal and you can select a single drum voice for any trigger input source.



### STORE the kit to User Memory:

4. Press the **[ENTER/STORE]** button and the following screen is displayed:

Select the User kit destination