

## YAMAHA DTX900 QUICK START – SONG MODE

### PLAY a Preset SONG:

Press the **[SONG]** mode button, then press **[F1] PLAY** to access the song play function page. With the Song number ① highlighted, use the jog-dial or INC/DEC buttons to select a PRESET Song 01-47. When a preset song is selected the category is shown at right of the song number.



Selecting a song will automatically select a drum kit. To play any kit in any song, select the kit you want in DRUM KIT mode *first*, then enter SONG mode and press **[F6] KIT LOCK** to lock in your kit.

Press **[▶/■]** to start/stop the song. Use the sliders to set the volume for ACCOMP and DRUMS.

### MUTE the DRUM part, BASS part or OTHER parts:

Press **[SF1]** to mute the **DRUM** part, **[SF2]** to mute the **BASS**, and **[SF3]** to mute all **OTHER** parts.

### RECORD your performance using a Preset Song:

By copying a song to the USER memory, you can record your own drum part.

</