


# YAMAHA DTXTREME III QUICK START – CLICK MODE & GROOVE CHECK

## CLICK Setup

1. Press the **[CLICK]** mode button  and **[F1] PLAY** button to enter Click play mode.

Highlight parameters with the arrow keys and set click values with the jog-dial or INC/DEC buttons.




## GROOVE CHECK Setup


2. While in CLICK mode, press the **[F4] GROOVE** button then the **[SF3] SETTING** button.

**TIP: Set the note value to an 8<sup>th</sup> note for this example**

Determines the note value for Groove Check ① ② Available only for 8<sup>th</sup> note triplet\* sets "correct" value +/- nearest 16<sup>th</sup> note



3. While in CLICK mode, press **[F4] GROOVE** then **[SF1] G.CHECK** to enter groove check mode. Use the cursor to highlight the area on the left ① and **select up to five inputs** for rhythmic analysis.



4. As you **play** along to a click (or song), Groove Check displays the timing of your hits that correspond to the note value you selected in step 2.

Early hits appear to the left and late hits appear to the right.

The interval between far left and far right is the length of a 16<sup>th</sup> note.

Groove Check gives you a powerful tool to improve technique and sharpen your time keeping skills.

This white line represents the average timing of all your hits so far in this session.

Actual timing at which the pad was hit last.

Center line; indicates the correct timing.

This crosshatch area indicates the range of all your hits so far in this session.



For a video demonstration of Click mode & Groove Check go to:

[www.DTXPERIENCE.com](http://www.DTXPERIENCE.com)