


YAMAHA DTXTREME III QUICK START – SONG MODE

PLAY a Preset SONG:

Press the **[SONG]** mode button, then press **[F1] [PLAY]** to access the song play function page. With the Song number ① highlighted, use the jog-dial or INC/DEC buttons to select a PRESET Song 01-87. When a preset song is selected the category is shown at right of the song number.



Selecting a song will automatically select a drum kit. To play any kit in any song, select the kit you want in DRUM KIT mode *first*, then enter SONG mode and press **[F6] KIT LOCK** to lock in your kit.

Press **[▶/■]** to start/stop the song and use the sliders to set the volume for ACCOMP and DRUMS.

MUTE the DRUM part, BASS part or OTHER parts:

Press **[SF1]** to mute the **DRUM** part, **[SF2]** to mute the **BASS**, and **[SF3]** to mute all **OTHER** parts.

RECORD your performance using a Preset Song:


By copying a song to the USER memory, you can record your own drum part.

1. Select an empty USER SONG. Press the **[F2] JOB** button, then **[SF1] SONG** for the song jobs.



2. Use the jog-dial or up/down arrows to highlight the Copy Song job and press **[ENTER]** button. Select the song you want to copy and press **[ENTER]**, then **[YES]** to confirm.

3. Press **[REC]** and choose “**replace**” for record type and track “**2**” as the track for recording. Mute the pre-recorded drums with the **[SF1]** button.



4. Press the **[▶/■]** button to begin recording. Recording will stop at the end of the song or if **[▶/■]** is pressed before the end of the song. Press the **[▶/■]** button again to hear your recorded performance.

If you want to **clear a track and re-record**, use the **[F2] JOB** and **[SF2] TRACK** buttons to access the Track Job list. Select Track 2 (the track you recorded on) then **ENTER**, and **YES** to confirm.

For a video demonstration of Song mode go to:

www.DTXPERIENCE.com