

YAMAHA DTXTREME III QUICK START – VOICE SELECT

PLAY the DRUM KIT:

Press the [DRUM KIT] mode button, then press [F1] [PLAY] to access the main kit play mode. Use the jog-dial or the INC/DEC buttons to select a drum kit in the PRESET Bank 01-50.

Change the drum VOICE SET:

A VoiceSet assigns *multiple sounds* to all sources of a multi-zone INPUT in one step.

1. While in DRUM KIT mode, press [F2] VOICE to access voice functions. Note the screen now includes several icons above the SF or “sub-function” keys. Press [SF1] to access voice **SELECT**.
2. Strike any zone of a trigger to select that trigger INPUT^① for editing. Use the cursor to highlight the Voice Set number^③. Rotate the jog-dial or press the INC/DEC buttons to select a new Voice Set. If desired, you can change the category of Voice Set^② to the left of the voice set number.




NOTE how the icons above the [SF1-SF4] keys are square but the “Source” and “key” icons have rounded edges? Square icons represent pages and rounded icons indicate a button (or switch).

Change the drum VOICE:

A *single* drum Voice can be assigned to any SOURCE from a multi-zone pad/trigger.

3. From Drum Kit [F2] VOICE → [SF1] SELECT page press the [SF5] SOURCE^④ button¹. Strike a trigger zone or kick the pedal and you can select a single drum voice for any trigger input source.



STORE the kit to User Memory:

4. Press the [ENTER/STORE] button and the following screen is displayed:

Select the User kit destination and press [ENTER], then confirm by pressing [INC/YES].



For a video demonstration of Voice Editing go to:

www.DTXPERIENCE.com

¹ If the screen above the SF5 button reads “INPUT” then you are already looking at the Voice Select page for a trigger SOURCE.