

# Yamaha Bass Drum Hoop Part #'s Chart



POWER LITE MARCHING BASS DRUM HOOPS			
Size	Solid Black	White Inlay	
16"	U0072650	Discontinued	
18"	U0072660	U0072013	
20"	U0072670	U0072033	
22"	U0072680	U0072053	Older model
24"	U0072690	U0072073	
26"	U0072700	U0072093	
28"	U0072710	U0072403	

8100 SERIES MARCHING BASS DRUM HOOPS					
Size	White	Silky Silver	Black Forest	Red Forest	Blue Forest
	White Inlay	Silver Inlay	No Inlay	No Inlay	No Inlay
	Part Number	Part Number	Part Number	Part Number	Part Number
16"	U0072411	U0072412	U0072413	U0072414	U0072415
18"	U0072111	U0072110	U0072113	U0072114	U0072115
20"	U0072121	U0072120	U0072123	U0072124	U0072125
22"	U0072131	U0072130	U0072133	U0072134	U0072135
24"	U0072141	U0072140	U0072143	U0072144	U0072145
26"	U0072151	U0072150	U0072153	U0072154	U0072155
28"	U0072161	U0072160	U0072163	U0072164	U0072165
30"	U0072171	U0072170	U0072173	U0072174	U0072175
32"	U0072181	U0072180	U0072183	U0072184	U0072185

Note: the 8100 Series was replaced in 2003 with the 8200 Series

8200 SERIES MARCHING BASS DRUM HOOPS					
Size	White	Silky Silver	Black Forest	Red Forest	Blue Forest
	White Inlay	Silver Inlay	No Inlay	No Inlay	No Inlay
	Part Number	Part Number	Part Number	Part Number	Part Number
14"	U0074501	U0074502	U0074503	U0074504	U0074505
16"	U0074511	U0074512	U0074513	U0074514	U0074515
18"	U0074521	U0074522	U0074523	U0074524	U0074525
20"	U0074531	U0074532	U0074533	U0074534	U0074535
22"	U0074541	U0074542	U0074543	U0074544	U0074545
24"	U0074551	U0074552	U0074553	U0074554	U0074555
26"	U0074561	U0074562	U0074563	U0074564	U0074565
28"	U0074571	U0074572	U0074573	U0074574	U0074575
30"	U0074581	U0074582	U0074583	U0074584	U0074585
32"	U0074591	U0074592	U0074593	U0074594	U0074595