


STEREO PAIR

You can use two WX-010 units to reproduce stereo sound by setting each speaker as the right or left speaker.

Set the left and right speakers separately by following the steps below.



Note

- To use the Stereo Pair function, you need two WX-010.
- Stereo Pair is available only when the Network Standby of the unit is enabled.(refer to the owner's manual).

Setting/Playing back music

1 Connect each WX-010 to the same network by using the dedicated app “MusicCast CONTROLLER.”


If the WX-010 is linked to another MusicCast unit, first disconnect the link by using the dedicated app “MusicCast CONTROLLER.”

2 Tap (power)/CONNECT of each unit to set them to standby.

3 Tap and hold the following together for 3 seconds to set the left/right speakers.

① For setting the left speaker: and

Indicators light from right to left repeatedly (refer to (A) of the table), and the unit enters pairing standby.



② For setting the right speaker: and

Indicators light from left to right repeatedly (refer to (B) of the table), and the units start pairing.



Indicator display during the Stereo Pair

Stereo Pair status	Indicator display
Start Pairing/ Checking the Left and Right Speaker	<p>(A) Left speaker (B) Right speaker</p> <p>Right-to-Left Left-to-Right</p>
Pairing Completed	<p>(C)</p> <p>Center to both sides</p>

After pairing is completed, the indicators light from the center to both sides (refer to (C) of the table), and all indicators return to the normal status.

4 Use the dedicated app “MusicCast CONTROLLER” to play back.



- You can check which speaker is the left or right speaker with the dedicated app “MusicCast CONTROLLER” (Indicators light as (A) or (B) of the table).
- In Stereo Pair mode, you can operate one speaker to simultaneously turn off both speakers or adjust the volume of both speakers.
- If about five minutes passes while the unit cannot find the other speaker to connect to, the pairing standby will be cancelled automatically.
- When in Stereo Pair mode, the option settings other than “Initialize the unit.” (refer to the owner's manual) cannot be set.

Note

The Stereo Pair setting remains even if the speakers enter standby or the power cable is unplugged and plugged again.

Canceling Stereo Pair

1 Tap  (**power**)/**CONNECT** to set the left and right speakers to the standby.

2 Tap and hold  (or ) and  on either speaker together for 3 seconds.

Indicators light from both sides to the center and Stereo Pair will be canceled.

Indicator display



Both sides to center

Note

- The Stereo Pair can be canceled only during standby.
- If you cancel Stereo Pair with one of the two speakers, the other one will be canceled automatically.
- If one of the two speakers is disconnected from the network when canceling the Stereo Pair, cancel Stereo Pair on each speaker.