Compatibility Table

In some cases, the Pickup Mute™ may not fit instruments that have significantly different bell diameters and/or shapes. Please check before purchasing. The Pickup Mute™ is not compatible with Piccolo Trumpets, Alto (Tenor) Horns, Baritones, Alto Trombones, Bass Trombones and Marching Brass Instruments.

Instrument: Pickup $Mute^{TM}$ fits into the bell, Fine Intonation, Personal StudioTM acts correctly Original Case: The instrument fits into the original case with Pickup $Mute^{TM}$

SILENT Brass™ SB7J / Pickup Mute™ PM7X

(for Trumpet and Cornet)

Model		Instrument	Original Case
B♭ Trumpet	YTR-2330(S), YTR-3335(S), YTR-4335G(S)II, YTR-5335G(S)II, YTR-5330MRC, YTR-6335(S), YTR-6335RC, YTR-6345G(S), YTR-8310Z(S), YTR-8330EM, YTR-850(G)S, YTR-8335(S)/G(S)/R(S)/RGS, YTR-8335WS, YTR-8335GH, YTR-8335LA(S), YTR-8345(S)/G(S)/RS, YTR-9335CHS, YTR-9335NYS	✓	√
C Trumpet	YTR-8445(S)/G(S), YTR-8445WS, YTR-9445CHS, YTR-9445NYS(-YS)/(-YM)	✓	✓
C/B b Trumpet	YTR-4435(S)II	✓	
E/E b Trumpet	YTR-9635	✓	
E b / D Trumpet	YTR-9636	✓	✓
	YTR-6610S, YTR-9610		
G/F Trumpet	YTR-9710		
Rotary B b Trumpet	YTR-938FFMS	✓	✓
Rotary C Trumpet	YTR-948FFMS	✓	✓
Fanfare Trumpet	YTR-6335F(S)	✓	✓
B♭ Cornet	YCR-2310(S)III, YCR-2330(S)III, YCR-4330G(S)II, YCR-6335(S)II, YCR-8335(S)/G(S)	✓	√
C Cornet	YCR-9435	✓	✓
E b Cornet	YCR-2610SIII	✓	
	YCR-8620(S)		

SILENT Brass™ SB6J / Pickup Mute™ PM6X

(for Flugelhorn)

Model		Instrument	Original Case
Flugelhorn	YFH-631G(S), YFH-8310Z(S)/ZG(S), YFH-8315G(S)	✓	

SILENT Brass™ SB5J / Pickup Mute™ PM5X-2

(for Tenor & Tenor BassTrombone)

Model			Instrument	Original Case
Tenor Trombone	Trombone Bell Size 7 1/2"	YSL-897Z	✓	✓
	Bell Size 8"	YSL-455G, YSL-354(S), YSL-350C, YSL-154	✓	✓
		YSL-891Z, YSL-895EN	✓	
		YSL-891ZD	✓	
	Bell Size 8 1/2"	YSL-445G, YSL-447G, YSL-610, YSL-630	✓	✓
	Bell Size 8 2/3"	YSL-881(G)	✓	✓
Tenor Bass Trombone	Bell Size 8"	YSL-456G	✓	✓
	Bell Size 8 1/2"	YSL-446G, YSL-448G, YSL-548GO, YSL-620, YSL-640, YSL-820GII, YSL-823G	✓	✓
		YSL-823GD	✓	
	Bell Size 8 2/3"	YSL-882(G), YSL882(G)O, YSL-882(G)OR, YSL-825(G)	✓	✓
		YSL-8820D	✓	
Valve Trombone	Bell Size 8"	YSL-354V, YSL-354VC	✓	
Bass Trombone	Bell Size 9 1/2"	YBL-835(G), YBL-822G, YBL-620G, YBL-421G	✓	✓
		YBL-835(G)D	✓	

SILENT Brass™ SB3J / Pickup Mute™ PM3X

(for French Horn)

(101 110110111)				
Model			Instrument	Original Case
French Horn	Bell Size MS	YHR-869(G)D, YHR-881(D), YHR-882(D), YHR-891(D), YHR-892(D)	✓	√ (*)
	Bell Size M	YHR-567/D/G(D)B, YHR-314II, YHR-322II, YHR-671(D)/G(D), YHR-871(D)/G(D)	✓	√ (*)
	Bell Size ML	YHR-881(D)U, YHR-882(D)U, YHR-891(D)U, YHR-892(D)U	✓	√ (*)
	Bell Size L	YHR-822GD, YHR-832GD, YHR-841GD	✓	√ (*)
	Bell Size LL	YHR-668(D)/N(D)/(D)II/N(D)II, YHR-868GD	✓	√ (*)

^{*} The PM3X can be kept in the one-piece bell and put in the case, or it can be put in the accessory pocket of the detachable bell case.

SILENT Brass™ SB2J / Pickup Mute™ PM2X

(for Euphonium)

(ioi zapiioiiiaiii)			
Model		Instrument	Original Case
Euphonium	YEP-201(S), YEP-321(S), YEP-621(S), YEP-642(S)II/T(S), YEP-842S/TS	✓	✓
	YEP-211(S)		
Marching Euphonium	YEP-201M(S), YEP-321M(S)	*	✓
	YEP-202M(S)		

^{*} Only concert configuration

Please Note:

SB2J and PM2X are not compatible with Alto (Tenor) Horns, or Baritones.

Push the mute deeper in the bell following the instructions of manual attached manual.

When inserting and removing the instrument with mute to/from the case, put in/out the instrument keeping the instrument parallel to the shape of the case.

SILENT Brass™ SB1J / Pickup Mute™ PM1X

Model		Instrument	Original Case
Bb Tuba	YBB-105(S), YBB-201(S)/II(S), YBB-321(S)/II(S), YBB-621(S), YBB-623(S)	✓	
	YBB-632(S), YBB-641/II, YBB-645G, YBB-841(G)	✓	✓
C Tuba	YCB-621(S), YCB-623(S)	✓	
	YCB-822(S), YCB-861	✓	✓
Eb Tuba	YEB-201(S), YEB-321(S), YEB-632(S)	✓	
F Tuba	YFB-822(S), YFB-621(S)	✓	
Marching Tuba	YBB-105M(S), YBB-201M(S), YBB-321M(S)	*	
	YBB-202M(S)		
Sousaphone	YSH-301, YSH-411(S)		

^{*} Only concert configuration

Please Note:

Push the mute deeper in the bell following the instructions of manual attached manual.

When inserting and removing the instrument with mute to/from the case, put in/out the instument keeping the instrument parallel to the shape of the case. Please Note

In some cases, the Pickup Mute™ may not fit instruments that have significantly different bell diameters and/or shapes. Please check before purchasing. The Pickup Mute™ is not compatible with Marching Mellophones, Marching French Horns, Alto (Tenor) Horns, or Baritones.

The SILENT Brass™ mute for Trombone (SB5J) and the Pickup Mute™ (PM5X-2) are not compatible with Alto Trombones.

The SILENT Brass™ mutes for Flugelhorn (SB6J) and the Pickup Mute (PM6X) protrudes 3-4 cm from the bell.

For information on compatibility with Yamaha brass instruments and cases please refer to the "Compatibility Table".

Always remove the Pickup Mute $^{\text{TM}}$ from the instrument if the instrument is to be stored for an extended period of time.

Do not connect the PHONE jack to a microphone input jack (or combined mic/line input) on a computer, etc., that also supplies power to the connected device (plug-in power). Please note that Brass Resonance Modeling™ is only available when the STJ Personal Studio™ is combined with a PM3X/5X-2/6X/7X Pickup Mute™. It is not available with any other Personal Studio™ or Pickup Mute™ models.

AA batteries are not supplied. Please purchase separately.

SILENT Brass™, Personal Studio™, Pickup Mute™, Brass Resonance Modeling™, and SILENT Brass™ logo are all trademarks owned by the Yamaha Corporation.