

Bass Drum Hoop Part Number Chart



| | Drum Color | White | Black Forest | Red Forest | Blue Forest |
|--|------------|-------------|--------------|-------------|-------------|
| | Size | Part Number | Part Number | Part Number | Part Number |
| 3300 Marching Bass Drum Hoop Part Numbers | 14" | ZH417900 | ZH418100 | ZH418200 | ZH418300 |
| | 16" | ZH418400 | ZH418600 | ZH418700 | ZH418800 |
| | 18" | ZH418900 | ZH419100 | ZH419200 | ZH419300 |
| | 20" | ZH419400 | ZH429600 | ZH420700 | ZH429800 |
| | 22" | ZH419900 | ZH420100 | ZH420200 | ZH420300 |
| | 24" | ZH420400 | ZH420600 | ZH420700 | ZH420800 |
| | 26" | ZH420900 | ZH421100 | ZH421200 | ZH421300 |
| | 28" | ZH421400 | ZH421600 | ZH421700 | ZH421800 |
| | 30" | ZH421900 | ZH422100 | ZH422200 | ZH422300 |
| | 32" | ZH422400 | ZH422600 | ZH422700 | ZH422800 |

| | Size | 6300 Series |
|--|------|-------------|
| Power Lite Marching Bass Drum Hoop Part Numbers | 16" | WY238600 |
| | 18" | WY238800 |
| | 20" | WY239000 |
| | 22" | WY239100 |
| | 24" | WY239200 |
| | 26" | WY239300 |
| | 28" | WY239400 |