

Available functions for each instrument

Updated: 2023/10

Functions		Instruments		TransAcoustic Piano		Silent Piano		AvantGrand				Standalone		
				TA2	TA3 TC3	SC2 SH2	SC3 SH3	NU1X	NU1XA	N1X	N3X			
Piano Room	Piano Room Setting	Lid Position			yes	yes	yes	yes	yes	yes	yes	yes	-	
		Brightness			-	-	-	-	-	yes	-	-	-	-
		Touch Curve			-	-	-	-	-	yes	-	-	-	-
		Environment			yes	yes	yes	yes	yes	yes	yes	yes	yes	-
		Master Tune			yes	yes	yes	yes	yes	yes	yes	yes	yes	-
		VRM			yes	yes	yes	yes	yes	yes	yes	yes	yes	-
		Damper Resonance			yes	yes	yes	yes	yes	yes	yes	yes	yes	-
		Damper Noise			-	yes	-	yes	-	yes	-	-	-	-
		String Resonance			yes	yes	yes	yes	yes	yes	yes	yes	yes	-
		Duplex Scale Resonance			yes	yes	yes	yes	yes	yes	-	-	-	-
		Body Resonance			yes	yes	yes	yes	yes	yes	-	-	-	-
		Grand Expression Modeling			-	yes	-	yes	-	yes	-	-	-	-
		Key Off Sampling			yes	-	yes	-	-	-	-	-	-	-
		Half Pedal Point			yes	yes	yes	yes	yes	yes	yes	yes	yes	-
		Each Key Setting			yes	yes	yes	yes	yes	yes	yes	yes	yes	-
		Voice	Voice Select											
Layer													-	
Left, Split Point													-	
Voice Setting	Octave													-
	Mixer		Volume											-
			Pan											-
	Reverb											-		
Style	Playback, FF, Rewind	(Audio Song)			yes	yes	yes	yes	yes	yes	yes	yes	yes	
		(MIDI Song - Preset)			yes	yes	yes	yes	yes	yes	yes	yes	yes	
		(MIDI Song - User)			yes	yes	yes	yes	yes	yes	yes	yes	yes	
	AB Repeat	(Audio Song)			yes	yes	yes	yes	yes	yes	yes	yes	yes	
		(MIDI Song)			-	-	-	-	-	yes	-	-	-	
	Guide (MIDI Song)			-	-	-	-	-	-	-	-	-	-	
	Volume	(Audio Song)			yes	yes	yes	yes	yes	yes	yes	yes	yes	
		(MIDI Song)			yes	yes	yes	yes	-	yes	-	-	-	
	Tempo	(Audio Song)			yes	yes	yes	yes	yes	yes	yes	yes	yes	
		(MIDI Song)			yes (*1)	yes (*1)	yes (*1)	yes (*1)	yes (*1)	yes	yes	yes	-	
	Transpose	(Audio Song)			yes	yes	yes	yes	yes	yes	yes	yes	yes	
		(MIDI Song)			yes	yes	yes	yes	-	yes	-	yes	-	
	Part (MIDI Song)	Right, Left			-	yes	-	yes	-	yes	-	-	-	
		Backing			-	-	-	-	-	yes	-	-	-	
	PDF Score	Viewer			yes	yes	yes	yes	yes	yes	yes	yes	yes	
		Playback			yes	yes	yes	yes	yes	yes	yes	yes	yes	
	Score Screen			yes	yes	yes	yes	yes	yes	yes	yes	yes	-	
	Chord Screen			yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	
	Lyrics Screen			yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	
	Audio Song Analysis	Audio to Score			-	-	-	-	-	-	-	-	-	
		Chord Analysis			yes	yes	yes	yes	yes	yes	yes	yes	yes	
	Chord Edit	Copy, Delete, Undo			yes	yes	yes	yes	yes	yes	yes	yes	yes	
					yes	yes	yes	yes	yes	yes	yes	yes	yes	
					yes	yes	yes	yes	yes	yes	yes	yes	yes	
		Arrangement (Audio Song)	Audio to Score Setting			-	-	-	-	-	-	-	-	-
			Backing			-	-	-	-	-	-	-	-	-
			Melody Suppressor			yes	yes	yes	yes	yes	yes	yes	yes	
		Playback	Stream Lights / Guide Lamp			-	-	-	-	-	-	-	-	-
			Guide Type (MIDI Song)			-	-	-	-	-	-	-	-	-
			Quick Start (MIDI Song)			-	-	-	-	-	yes	-	-	-
MIDI Part Channel (MIDI Song)					-	-	-	-	-	-	-	-	-	
Score				yes	yes	yes	yes	yes	yes	yes	yes	yes		
Chord				yes	yes	yes	yes	yes	yes	yes	yes	yes		
Lyrics			yes	yes	yes	yes	yes	yes	yes	yes	yes			
Mixer			-	-	-	-	-	-	-	-	-			
Song Edit	Quantize (MIDI Song)			yes	yes	yes	yes	yes	yes	yes	yes	-		
	Delete, Mix, Setup (MIDI Song)			-	-	-	-	-	-	-	-	-		
	Trimming (Audio Song)			yes	yes	yes	yes	yes	yes	yes	yes	-		
Recording	Audio Recording (*2)			yes	yes	yes	yes	yes	yes	yes	yes	-		
	Audio Overdub Recording (*2)			yes	yes	yes	yes	yes	yes	yes	yes	-		
	MIDI Recording			yes	yes	yes	yes	yes	yes	yes	yes	-		
	MIDI Multitrack Recording			-	-	-	-	-	-	-	-	-		
Metronome	Metronome			yes	yes	yes	yes	yes	yes	yes	yes	-		
	Rhythm	Bass On/Off			-	yes	-	-	-	-	-	-		
Balance				-	yes	-	yes	-	-	-	-	-		
				-	yes	-	yes	-	yes	-	-	-		
Registration Memory				yes	yes	yes	yes	yes	yes	yes	yes	-		
				yes	yes	yes	yes	yes	yes	yes	yes	-		
Utility	Transpose	Master Tune			yes	yes	yes	yes	yes	yes	yes	yes		
		Scale Tune			yes	yes	yes	yes	yes	yes	yes	yes		
		Touch Curve			yes	yes	yes	yes	yes	yes	yes	yes		
	Keyboard Setting	TRS			-	-	-	-	-	-	-	yes		
					-	-	-	-	-	-	-	-		
	Pedal Setting	Function Assign	Score Page Turning			-	-	-	yes	yes	yes	yes		
			Half Pedal Point			yes	yes	yes	yes	yes	yes	yes		
		AUX Pedal Polarity			-	-	-	-	-	-	-	-		
	Mic Setting	Vocal Harmony			-	-	-	-	-	-	-	-		
	Master EQ				-	-	-	-	-	-	-	-	-	
					-	-	-	-	-	-	-	-	-	
					yes	yes	yes	yes	-	yes	-	-	-	
					-	-	-	-	-	yes	-	-	-	
		Sound Setting	Brilliance			yes	yes	yes	yes	-	yes	-	-	-
			Speaker Setting			-	-	-	-	-	-	-	-	-
			Binaural / Stereophonic Optimizer			Binaural	Binaural	Binaural	Binaural	Binaural	Binaural	Binaural	Binaural	-
			Lid Position / TA Mode Tone Control			yes	yes	-	-	-	-	-	-	-
			IAC (Intelligent Acoustic Control)			yes	yes	-	yes	yes	yes	yes	yes	
			Sound Boost			-	-	-	-	-	-	-	-	-
			Wall EQ			-	-	-	-	-	-	-	-	-
			AUX Out Volume			-	-	-	-	-	-	-	-	-
	Volume Limiter			-	-	-	-	-	-	-	-	-		
	AUX In Noise Gate			yes	yes	yes	yes	yes	-	yes	yes	-		
	Version, Language, Manual, FAQ			yes	yes	yes	yes	yes	yes	yes	yes	yes		
Audio Rec Format			yes	yes	yes	yes	yes	yes	yes	yes	-			
Auto Power Off			yes	yes	yes	yes	yes	yes	yes	yes	-			
Firmware Version, Firmware Update			-	-	-	-	-	-	-	-	-			
Factory Reset			yes	yes	yes	yes	yes	yes	yes	yes	-			
Backup, Restore			yes	yes	yes	yes	yes	yes	yes	yes	-			
Demo	Wi-Fi (*3)	UD-WL01			yes	yes	yes	yes	yes	yes	-	-		
	Bluetooth (*2) (*3)	Built-in			-	yes	-	-	yes	-	-	-		
		UD-BT01 (for iPhone / iPad)			-	-	-	-	-	-	-	-		
	USB cable (for iPhone / iPad with Lightning terminal)	Lighting - USB cable				-	-	-	-	-	-	-	-	
		Lighting to USB Camera Adapter + USB cable (Type A plug - Type B plug)			yes	yes	yes	yes	yes	yes	yes	yes	-	
		Lighting to USB Camera Adapter + USB cable (Type A plug - Type C plug)			-	-	-	-	-	-	-	-	-	
		USB-C - Lightning cable			-	-	-	-	-	-	-	-	-	
	USB cable (for iPhone / iPad with Type-C terminal)	USB-C Digital AV Multiport Adapter or USB-C VGA Multiport Adapter + USB cable (Type A plug - Type B plug)			yes	yes	yes	yes	yes	yes	yes	yes	-	
		USB-C Digital AV Multiport Adapter or USB-C VGA Multiport Adapter + USB cable (Type A plug - Type C plug)			-	-	-	-	-	-	-	-	-	
		USB cable (Type C plug - Type C plug)			-	-	-	-	-	-	-	-		
USB cable (for Android devices with Type-C Terminal)	USB On-The-Go adapter (Type C plug - Type A socket) + USB cable (Type A plug - Type B plug)			yes	yes	yes	yes	yes	yes	yes	yes	-		
	USB On-The-Go adapter (Type C plug - Type A socket) + USB cable (Type A plug - Type C plug)			-	-	-	-	-	-	-	-	-		
	USB cable (Type-C - Type-C)			-	-	-	-	-	-	-	-			

(*1) Tempo can be changed while song is playing.
 (*2) During Bluetooth connection, audio recording function is not available.
 (*3) Availability varies by area.

Available functions for each instrument
Updated: 2023/10

Functions			Clavinova CLP						Clavinova CSP			Clavinova CVP		SCLP			Standalone	
			CLP-635 CLP-645 CLP-665GP CLP-675	CLP-685 CLP-695GP	CLP-725	CLP-735	CLP-745 CLP-765GP CLP-775	CLP-785 CLP-795GP	CSP-150 CSP-170	CSP-255 CSP-275 CSP-295 CSP-295GP	CVP-805 CVP-809	CVP-905 CVP-909	SCLP-6350 SCLP-6450	SCLP-7350	SCLP-7450			
Piano Room	Piano Room Setting	Lid Position	yes	yes	yes	yes	yes	yes	yes	-	-	yes	yes	yes	-			
		Brightness	yes	yes	-	yes	yes	yes	yes	-	-	yes	yes	yes	-			
		Touch Curve	yes	yes	-	yes	yes	yes	yes	-	-	yes	yes	yes	-			
		Environment	yes	yes	yes	yes	yes	yes	yes	-	-	yes	yes	yes	-			
		Master Tune	yes	yes	yes	yes	yes	yes	yes	-	-	yes	yes	yes	-			
		VRM	yes	yes	yes	yes	yes	yes	yes	-	-	yes	yes	yes	-			
		Damper Resonance	yes	yes	-	yes	yes	yes	yes	-	-	yes	yes	yes	-			
		Damper Noise	-	-	-	yes	yes	yes	-	-	-	-	yes	yes	-			
		String Resonance	yes	yes	-	yes	yes	yes	yes	-	-	yes	yes	yes	-			
		Duplex Scale Resonance	yes	yes	-	yes	yes	yes	-	-	-	yes	yes	yes	-			
		Body Resonance	yes	yes	-	yes	yes	yes	-	-	-	yes	yes	yes	-			
		Grand Expression Modeling	-	-	yes	yes	yes	yes	-	-	-	-	yes	yes	-			
		Key Off Sampling	yes	yes	-	yes	yes	yes	-	-	-	yes	yes	yes	-			
		Half Pedal Point	yes	yes	-	yes	yes	yes	yes	-	-	yes	yes	yes	-			
		Each Key Setting	yes	yes	yes	yes	yes	yes	yes	-	-	yes	yes	yes	-			
		Voice	Voice Select	Layer	yes	yes	yes	yes	yes	yes	-	-	yes	yes	yes	-		
			Left, Split Point	Octave	yes	yes	yes	yes	yes	yes	-	-	-	-	-	-		
Voice Setting	Mixer		Volume	yes	yes	yes	yes	yes	yes	-	-	-	-	-	-			
	Pan		Reverb	yes	yes	-	yes	yes	yes	-	-	-	-	-	-			
				yes	yes	yes	yes	yes	yes	-	-	yes	yes	yes	-			
			yes	yes	-	yes	yes	yes	-	-	-	-	-	-				
			yes	yes	-	yes	yes	yes	-	-	-	-	-	-				
Style	Playback, FF, Rewind	(Audio Song)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-		
		(MIDI Song - Preset)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-		
		(MIDI Song - User)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-		
	AB Repeat	(Audio Song)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes		
		(MIDI Song)	yes	yes	-	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-		
	Guide (MIDI Song)	(Audio Song)	-	-	-	-	-	yes	yes	yes	yes	-	-	-	-	-		
		(MIDI Song)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes		
		(MIDI Song)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes		
	Tempo	(Audio Song)	yes	yes	yes (*1)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-		
		(MIDI Song)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-		
	Transpose	(Audio Song)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes		
		(MIDI Song)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-		
	Part (MIDI Song)	Right, Left	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-		
		Backing	yes	yes	-	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-		
	PDF Score	Viewer	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes		
		Playback	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes		
	Song	Score Screen	Chord Analysis	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-	
			Chord Edit	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-	
		Audio Song Analysis	Audio to Score	-	-	-	-	-	yes	yes	yes	yes	-	-	-	-	-	
			Chord Analysis	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	
		Song Setting	Copy, Delete, Undo	Arrangement (Audio Song)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes
				Audio to Score Setting	-	-	-	-	-	yes	yes	yes	yes	-	-	-	-	-
				Backing	-	-	-	-	-	yes	yes	yes	yes	-	-	-	-	-
			Playback	Melody Suppressor	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes
				Stream Lights / Guide Lamp	-	-	-	-	-	yes	yes	yes	yes	yes	yes	yes	yes	yes
				Guide Type (MIDI Song)	-	-	-	-	-	(Stream Lightes)	(Stream Lightes)	(Guide Lamp)	(Guide Lamp)	-	-	-	-	-
				Quick Start (MIDI Song)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-
			Score	MIDI Part Channel (MIDI Song)	-	-	-	-	-	yes	yes	yes	yes	yes	yes	yes	yes	-
	Score			yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-	
	Chord			yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	
	Lyrics	Lyrics	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes		
		Mixer	-	-	-	-	-	yes	yes	yes	yes	-	-	-	-	-		
	Song Edit	Quantize (MIDI Song)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-		
Delete, Mix, Setup (MIDI Song)		-	-	-	-	-	yes	yes	yes	yes	-	-	-	-	-			
Trimming (Audio Song)	Trimming (Audio Song)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-			
		-	-	-	-	-	yes	yes	yes	yes	-	-	-	-	-			
Recording	Audio Recording (*2)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-			
	Audio Overdub Recording (*2)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-			
	MIDI Recording	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-			
Metronome	MIDI Multitrack Recording	-	-	-	-	-	yes	yes	yes	yes	yes	yes	yes	yes	-			
	Metronome	yes	yes	yes	yes	yes	yes	yes	yes	-	-	yes	yes	yes	-			
Rhythm	Rhythm	yes	yes	-	yes	yes	yes	-	-	-	-	yes	yes	yes	-			
	Bass On/Off	-	-	-	-	-	yes	yes	yes	yes	yes	yes	yes	yes	-			
Balance	Registration Memory	Transposition	yes	yes	yes	yes	yes	yes	yes	yes	-	-	yes	yes	yes	-		
		Tuning	yes	yes	yes	yes	yes	yes	yes	yes	-	-	yes	yes	yes	-		
	Keyboard Setting	Master Tune	yes	yes	yes	yes	yes	yes	yes	yes	-	-	yes	yes	yes	-		
		Scale Tune	yes	yes	-	yes	yes	yes	yes	yes	-	-	yes	yes	yes	-		
	Pedal Setting	Touch Curve	yes	yes	yes	yes	yes	yes	yes	yes	-	-	yes	yes	yes	-		
		TRS	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
	Mic Setting	Function Assign	yes	yes	yes	yes	yes	yes	yes	yes	-	-	yes	yes	yes	-		
		AUX Pedal Polarity	yes	yes	-	yes	yes	yes	yes	yes	-	-	yes	yes	yes	-		
	Utility	Sound Setting	Score Page Turning	-	-	-	-	-	yes	yes	-	-	-	-	-	-		
			Half Pedal Point	-	-	-	-	-	yes	yes	-	-	-	-	-	-		
		Sound Setting	AUX Pedal Polarity	-	-	-	-	-	yes	yes	yes	-	-	-	-	-	-	
			Vocal Harmony	-	-	-	-	-	yes	yes	yes	-	-	-	-	-	-	
			Brilliance	-	-	-	yes	yes	yes	-	-	-	-	yes	yes	yes	-	
			Speaker Setting	yes	yes	yes	yes	yes	yes	yes	yes	-	-	yes	yes	yes	-	
			Binaural / Stereophonic Optimizer	Binaural	Binaural	Stereophonic Optimizer	Binaural	Binaural	Binaural	Binaural	Binaural	-	-	Binaural	Binaural	Binaural	-	
			Lid Position / TA Mode Tone Control	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
			IAC (Intelligent Acoustic Control)	yes	yes	yes	yes	yes	yes	yes	yes	-	-	yes	yes	yes	-	
		Sound Boost	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
		System	Wall EQ	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
	AUX Out Volume		-	-	-	-	-	-	-	-	-	-	-	-	-	-		
	Volume Limiter		-	-	-	-	-	-	-	-	-	-	-	-	-	-		
	AUX In Noise Gate		-	-	-	-	-	yes	yes	-	-	-	-	-	-	-		
	Demo	Connection	Version, Language, Manual, FAQ	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	
Audio Rec Format			yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-		
Auto Power Off			yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-		
Firmware Version, Firmware Update			-	-	-	-	-	-	yes	yes	-	-	-	-	-	-		
Factory Reset			yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-	
Backup, Restore	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-			
Wi-Fi (*3)	Bluetooth (*2) (*3)	UD-WL01	yes	yes	-	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-		
		Built-in	-	-	-	-	yes	yes	-	yes	-	-	-	yes	-	-		
		UD-BT01 (for iPhone / iPad)	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
		Lighting - USB cable	Lighting - USB cable	-	-	-	-	-	yes	-	-	-	-	-	-	-	-	
			Lightning to USB Camera Adapter + USB cable (Type A plug - Type B plug)	yes	yes	yes	yes	yes	yes	-	-	yes	yes	yes	yes	yes	-	
		USB cable (for iPhone / iPad with Lightning terminal)	Lightning to USB Camera Adapter + USB cable (Type A plug - Type C plug)	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
			USB-C - Lightning cable	-	-	-	-	-	-	yes	-	-	-	-	-	-	-	
		USB cable (for iPhone / iPad with Type-C terminal)	USB-C Digital AV Multiport Adapter or USB-C VGA Multiport Adapter + USB cable (Type A plug - Type B plug)	yes	yes	yes	yes	yes	yes	-	-	yes	yes	yes	yes	yes	-	
			USB-C Digital AV Multiport Adapter or USB-C VGA Multiport Adapter + USB cable (Type A plug - Type C plug)	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
		USB cable (for Android devices with Type-C Terminal)	USB cable (Type C plug - Type C plug)	-	-	-	-	-	-	yes	-	-	-	-	-	-	-	
			USB On-The-Go adapter (Type C plug - Type A socket) + USB cable (Type A plug - Type B plug)	yes	yes	yes	yes	yes	yes	yes	-	yes	yes	yes	yes	yes	-	
		USB cable (Type C - Type C)	USB On-The-Go adapter (Type C plug - Type A socket) + USB cable (Type A plug - Type C plug)	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
USB cable (Type-C - Type-C)	-		-	-	-	-	-	yes	-	-	-	-	-	-	-			

(*1) Tempo can be changed while song is playing.
(*2) During Bluetooth connection, audio recording function is not available.
(*3) Availability varies by area.

Available functions for each instrument

Updated: 2023/10

Functions			ARIUS				P						Plaggero	Standalone	
			YDP-105	YDP-144 YDP-164 YDP-S34 YDP-S54	YDP-145 YDP-165 YDP-S35 YDP-S55	YDP-184	P-121 P-125 P-128	P-125a YDP-S35	P-143 P-145	P-223 P-225	P-515	P-525	P-S500	NP-15 NP-35	from installing the app to connecting a supported instrument
Piano Room	Piano Room Setting	Lid Position	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-	
		Brightness	-	-	-	yes	-	-	-	yes	yes	yes	-	-	
		Touch Curve	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-	
		Environment	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-	
		Master Tune	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-	
		VRM	-	-	yes	yes	-	-	yes	yes	yes	yes	yes	-	
		Damper Resonance	yes (on/off only)	yes (on/off only)	-	yes	yes (on/off only)	yes (on/off only)	yes (on/off only)	-	yes	yes	yes	yes (on/off only)	-
		Damper Noise	-	-	-	-	-	-	-	-	-	yes	-	-	-
		String Resonance	-	-	-	yes	-	-	-	-	yes	yes	yes	-	-
		Duplex Scale Resonance	-	-	-	yes	-	-	-	-	yes	yes	-	-	-
		Body Resonance	-	-	-	yes	-	-	-	-	yes	yes	-	-	-
		Grand Expression Modeling	-	-	-	-	-	-	-	-	-	yes	-	-	-
Key Off Sampling	-	-	-	yes	-	-	-	-	yes	-	yes	-	-		
Half Pedal Point	-	-	-	yes	-	-	-	-	yes	yes	yes	-	-		
Each Key Setting	-	-	-	-	-	-	-	-	-	-	-	-	-		
Voice	Voice Select	Layer	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-	
	Left, Split Point	Octave	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-	
		Volume	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-	
	Voice Setting	Mixer	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-	
		Reverb	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-	
	Song	Playback, FF, Rewind	(Audio Song)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-
(MIDI Song - Preset)			yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-	
(MIDI Song - User)			-	yes	yes	yes	yes	yes	-	yes	yes	yes	-	-	
AB Repeat		(Audio Song)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	
		(MIDI Song)	-	-	-	yes	-	-	-	yes	yes	yes	-	-	
Guide (MIDI Song)		-	-	-	-	-	-	-	-	-	-	yes	-		
Volume		(Audio Song)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	
		(MIDI Song)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-	
Tempo		(Audio Song)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	
		(MIDI Song)	yes (*1)	yes (*1)	yes (*1)	yes	yes (*1)	yes (*1)	yes (*1)	yes	yes	yes	yes (*1)	-	
Transpose		(Audio Song)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	
		(MIDI Song)	-	yes	yes	yes	yes	yes	-	yes	yes	yes	-	-	
Part (MIDI Song)		Right, Left	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-	
		Backing	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-	
Viewer		PDF Score	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	
Score Screen	Chord Screen	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes		
Lyrics Screen	Audio Song Analysis	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes		
Song Setting	Chord Edit	Audio to Score	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes		
		Chord Analysis	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes		
	Arrangement (Audio Song)	Copy, Delete, Undo	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	
		Backing	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	
		Melody Suppressor	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	
		Stream Lights / Guide Lamp	-	-	-	-	-	-	-	-	-	-	yes (Stream Lights)	-	
		Guide Type (MIDI Song)	-	-	-	-	-	-	-	-	-	-	yes	-	
		Quick Start (MIDI Song)	-	yes	yes	yes	yes	yes	-	yes	yes	yes	-	-	
		MIDI Part Channel (MIDI Song)	-	-	-	-	-	-	-	-	-	-	yes	-	
		Score	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-	
Chord	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes			
Mixer	Lyrics	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes		
	Quantize (MIDI Song)	-	yes	yes	yes	yes	yes	-	yes	yes	yes	-	-		
Song Edit	Delete, Mix, Setup (MIDI Song)	-	-	-	-	-	-	-	-	-	-	yes	-		
	Trimming (Audio Song)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-		
Recording	Audio Recording (*2)	yes	yes	yes	yes	yes	-	yes	yes	yes	yes	yes	-		
	Audio Overdub Recording (*2)	yes	yes	yes	yes	yes	-	yes	yes	yes	yes	yes	-		
	MIDI Recording	-	yes	yes	yes	yes	yes	-	yes	yes	yes	-	-		
	MIDI Multitrack Recording	-	-	-	-	-	-	-	-	-	-	yes	-		
Metronome	Metronome	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-		
	Rhythm	-	-	-	yes	yes	yes	-	yes	yes	-	-	-		
Balance	Bass On/Off	-	-	-	-	yes	yes	-	yes	yes	-	-	-		
Registration Memory	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-		
Utility	Transpose	Master Tune	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-		
		Scale Tune	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-		
		Touch Curve	-	-	-	yes	-	-	-	yes	yes	yes	-		
	Keyboard Setting	TRRS	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-	
		Function Assign	-	-	-	-	-	-	-	-	-	-	yes	-	
	Pedal Setting	Score Page Turning	-	yes	yes	yes	yes	yes	-	yes	yes	yes	-		
		Half Pedal Point	-	-	-	yes	-	-	-	yes	yes	yes	-		
	AUX Pedal Polarity	-	-	-	-	-	-	-	yes	yes	yes	-			
	Mic Setting	Vocal Harmony	-	-	-	-	-	-	-	-	-	yes	-		
	Master EQ	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-		
	Sound Setting	Brightness	-	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-	
		Speaker Setting	-	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-	
		Binaural / Stereophonic Optimizer	-	Stereophonic Optimizer	Stereophonic Optimizer	Stereophonic Optimizer	Stereophonic Optimizer	Stereophonic Optimizer	Stereophonic Optimizer	Binaural	Binaural	Binaural	-		
		Lid Position / TA Mode Tone Control	-	-	-	-	-	-	-	-	-	-	-	-	
		IAC (Intelligent Acoustic Control)	-	yes	yes	yes	yes	yes	-	yes	yes	yes	-		
		Sound Boost	-	-	-	-	-	-	yes	yes	-	yes	-		
		Wall EQ	-	-	-	-	-	-	-	yes	-	-	-		
	AUX Out Volume	-	-	-	-	-	-	-	yes	-	-	-			
Volume Limiter	yes	-	yes	-	-	-	-	-	-	-	-				
AUX In Noise Gate	-	-	-	-	-	-	-	-	-	-	yes	-			
System	Version, Language, Manual, FAQ	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes		
	Audio Rec Format	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-		
	Auto Power Off	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-		
	Firmware Version, Firmware Update	-	-	-	-	-	-	-	-	-	-	yes	-		
	Factory Reset	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-		
Backup, Restore	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-			
Demo	-	-	-	-	-	-	-	-	-	-	yes	-			
Connection	Wi-Fi (*3)	UD-WL01	-	-	-	yes	-	-	-	yes	yes	yes	-		
		Built-in	-	-	-	-	-	-	-	-	yes	-	-		
	Bluetooth (*2) (*3)	UD-BT01 (for iPhone / iPad)	-	-	-	-	-	-	-	-	-	-	yes		
		Lighting - USB cable	-	-	-	-	-	-	-	-	-	-	yes		
	USB cable (for iPhone / iPad with Lightning terminal)	Lightning to USB Camera Adapter + USB cable (Type A plug - Type B plug)	yes	yes	yes	yes	yes	yes	yes	yes	yes	-	yes		
		Lightning to USB Camera Adapter + USB cable (Type A plug - Type C plug)	-	-	-	-	-	-	-	-	-	yes	-		
		USB-C - Lightning cable	-	-	-	-	-	-	-	-	-	-	-		
	USB cable (for iPhone / iPad with Type-C terminal)	USB-C Digital AV Multiport Adapter or USB-C VGA Multiport Adapter + USB cable (Type A plug - Type B plug)	yes	yes	yes	yes	yes	yes	yes	yes	yes	-	yes		
		USB-C Digital AV Multiport Adapter or USB-C VGA Multiport Adapter + USB cable (Type A plug - Type C plug)	-	-	-	-	-	-	-	-	-	-	-		
	USB cable (for Android devices with Type-C Terminal)	USB cable (Type C plug - Type C plug)	-	-	-	-	-	-	-	-	yes	-	-		
		USB On-The-Go adapter (Type C plug - Type A socket) + USB cable (Type A plug - Type B plug)	yes	yes	yes	yes	yes	yes	yes	yes	yes	-	yes		
	USB On-The-Go adapter (Type C plug - Type A socket) + USB cable (Type A plug - Type C plug)	-	-	-	-	-	-	-	-	-	-	-	-		
USB cable (Type-C - Type-C)	-	-	-	-	-	-	-	-	-	yes	-	-			

(*1) Tempo can be changed while song is playing.
 (*2) During Bluetooth connection, audio recording function is not available.
 (*3) Availability varies by area.