

Function...		Transmitted	Recognized	Remarks
Basic Channel	Default Changed	1 - 16 x	1 - 16 x	Memorized
Mode	Default Messages Altered	x x *****	x x x	
Note Number	: True voice	0 - 127 *****	0 - 127 0 - 127	
Velocity	Note ON Note OFF	o 9nH,v=1-127 x 9nH,v=0	o 9nH,v=1-127 x	
After Touch	Key's Ch's	o o	o o	
Pitch Bend		o	o	
Control Change	0-121	o	o	
Prog Change	: True #	o 0 - 127 *****	o 0 - 127	
System Exclusive		o	o	
Common	: Song Pos.	o	o	
	: Song Sel.	x	x	
	: Tune	x	x	
System	: Clock	o *2	o *3	
Real Time	: Commands	o *1	o *1	
Aux	: All Sound Off	o	o	
	: Reset All Cntrls	o	o	
	: Local ON/OFF	o	o	
Mes-	: All Notes OFF	o	o	
sages	: Active Sense	x	x	
	: Reset	x	x	
Notes: *1 if Song Play/Stop Receive/Transmit is on. *2 if MIDI Clock Out is on. *3 if MIDI Sync is MIDI.				